

0-1km

Hilti Corrosion handbook / DFTM

X-SEA-R 30 M8

Use with

	S-BT-GR M8		X-FCM-(M-R) X-FCM-R HL
	X-ST-GR M8/10 P8		
	X-BT-GR M8/7		

